

# サーキットブレーカ 取扱説明書

このたびは、弊社製品をお買い上げいただき誠にありがとうございます。 で使用の前に必ずこの説明書をよくお読みの上、正しくお使いください。 (この説明書は、必ず保管しておいてください。)

## 安全上のご注意

施工、使用(操作・保守・点検)の前に必ずこの説明書とその他の注意書きをすべて熟読し、 正しくで使用ください。機器の知識、安全の情報をして注意事項のすべてについて習熟してから で使用ください。この説明書では、安全注意事項のランクを「危険」「注意」として区分してあります。



取扱いを誤った場合に、危険な状況が起こりえて、 死亡又は重傷を受ける可能性が想定される場合。

⚠注意

取扱いを誤った場合に、危険な状況が起てります。 中程度の傷害を受ける可能性が想定される場合。 及び物的損害だけの発生が想定される場合。

お守りいただく内容を次の図記号で 区分しています。

★ 気をつけていただく内容です。

○ してはいけない内容です。

♠ 実行しなければならない内容です。

結びつく可能性があります。いずれも、重要な内容を記載していますの で必ず守ってください。

#### ■施工上のご注意

## ∧注意



無断で修理・改造等したことにより生じ た事故については、一切責任を負いま



高温、多湿、じんあい、腐食性ガス、振動 衝撃などの異常環境に設置しないで ださい。感電、火災や動作しないおそれ があります。

電気工事は、有資格者(電気工事士)が 行ってください。

配線作業は、上位ブレーカを「OFF」に し、電気がきていないことを確認して行 ってください。感電のおそれがあります。

ごみ、コンクリート粉、鉄粉、虫などの異 物および雨水などが製品内部に入らな いように施工してください。火災や動作 しないおそれがあります。



単相3線式専用の機種は、中性線を必 ず中性相に接続してください。また、中 性線欠相検出用リード線は負荷側の中 性相に確実に締付けてください。過電流 または中性線欠相で動作せずに火災の 原因となります。

4極ブレーカの場合、三相4線式の中 性線を中性相に接続してください。過電 流で動作せずに火災の原因となります。 また、2極1素子ブレーカの場合、電圧側 電線を左極に、接地側電線をN表示の ある右極に接続してください。

モータブレーカおよびモータ保護兼用 ブレーカをモータ回路に使用する場合 は、モータの全負荷電流に適合したブレ 一力を選定してください。

本体の定格にあった雷源に接続してく ださい。不動作および故障の原因となり

電源側と負荷側の表示のあるものは、 表示のとおりに正しく配線してください。 火災や故障の原因となります。

配線は適合した電線や銅バーを使用し てください。不要動作および火災のおそ れがあります。



インバータ回路には配線保護用として 一次側に設置してください。モータ保護 用としては使用できません。

端子に直接電線を接続する場合には、 単線またはより線をまっすぐ差込み適 正なトルクで締付けてください。直接、 市販の圧着端子またはバーを接続する こともできます。より線の場合は、電線を ふり分けて差込み締付けてください。





より線

#### ■施工上のご注意(つづき)

## ∧注意

電線接続の際、端子ねじを次の表に 適正締付トルク 従って確実に締付けてください。火災 ちょっの回 の原因となります。

WESTERNAM IN TANK	
ねじの呼び	締付トルク N・m
ソルダーレス端子	1.5~ 2.5
M5 (NX51A)	2.0~ 3.0
M5	2.3~ 3.4
M6	4.0~ 5.0
M8	4.6~ 6.9
M8(六角穴付)	8.0~ 13.0
M10	25.0~ 35.0
M12	40.0~ 50.0

### ■使用上のご注意

## ⚠危険




端子部に触れないでください。感電のおそれがあります。

#### 接触禁止

## ⚠注意

保守・点棒は、専門知識を有する人が上 位ブレーカを「OFF」にし、電気がきて いないことを確認して行ってください。 感電のおそれがあります。

有資格者にて増締めを行ってください。



いてからハンドルを「ON」にしてくださ い。火災のおそれがあります。また、ハン ドルは「OFF」の位置に止まるタイプ と、「ON」と「OFF」の中間で止まるタ イブがあります。中間で止まるタイプは、 一度「OFF」側に戻してから再投入し てください。


自動的に遮断した場合は、原因を取除

## ■各種設定ダイヤルの設定方法(汎用形)

·/g:定格雷流(1000·1250AF)

火災の原因となります。

- ·/;: 瞬時引外し雷流(400·600·800AF)
- Characteristics:保護特性(1000・1250AF)
- ①ブレーカを「OFF」にしてください。
- ②保護カバーを横へスライドさせて取外し てください。
- ③ ⊕ ドライバーまたは ⊖ ドライバーで 設定ダイヤルを回し、設定してください。
- ④保護カバーを元の位置に戻してください。



施工業者名				
TEL	施工年月日	年	月	B

仕様など、お断りなしに変更することがありますのでご了承ください。 また、ご不明な点がありましたら弊社お客様相談室にお問合わせください。 この説明書の内容は2015年3月現在のものです。

C905301

## 日東工業株式会社

〒480-1189 愛知県長久手市蟹原2201番地 お客様相談室/TEL (0561)64-0152 © NITTO KOGYO CORPORATION http://www.nito.co.jp

# **Circuit Breakers**

# Instruction Manual

Thank you for choosing our product.

Please read this manual carefully before use, to ensure proper use of the product, (Please make sure that you will not lose this manual.)

## Safety Instructions

Read this manual and all other relevant instructions thoroughly before installing, handling or operating the product or performing maintenance or inspection work on the product, and use the product correctly. Make sure that you have acquired the necessary knowledge about the product. before proceeding to use. The safety instructions contained herein are defined as "DANGER" and "CAUTION", depending on the degree of danger that will result from failure to follow the instructions.

Indicates that improper handling may result in a DANGER dangerous situation in which the risk of death or serious personal injury is present

Indicates that improper handling may result in a **CAUTION** dangerous situation in which the risk of medium personal injury or damage to property is present.

Note: Even if the items that described as "CAUTION" may lead to serious results depend on circumstances. All items contain important contents, therefore please observe them strictly.

 Instructions are labeled by the following symbols depending on how to deal with.

A You should heed.

You must not do.

You must do.

#### ■Instructions for Installation

## **ACAUTION**



We shall not be liable for any accidents caused by modifications and so forth.



Do not place the product in an area that is subject to high temperature, high humidity, excessive dusty air, corrosive gas, strong vibration and shock, or other unusual conditions. Mounting in such areas could cause a fire or malfunction.

Electrical work should only be undertaken by suitably qualified persons.

For the wiring work, open an upstream circuit breaker or th the like to isolate all sources of power. Otherwise, electric shock may result.

Be careful to prevent foreign objects (debris, concrete powder, iron powder, insect , etc.) and rainwater from entering product. These materials inside the product could cause a fire or malfunction.



In the case of a product that can only be used for single-phase, 3-wire systems, make sure that a neutral line is connected to the neutral phase. In addition, the neutral line open phase detection lead must be tightened securely on the load side's neutral phase. Otherwise, a fire due to failure to operate upon an open phase in the neutral line or an over-current may result.

For 4-pole breakers, be sure to connect a neutral conductor to the neutral pole. Otherwise, an over-current may hinder the product form tripping, thus resulting in a fire. In addition, in case of 2-pole 1-element breaker, the voltage wire connect to the left pole, and the ground wire connect to the N-pole at the right side.

When you use a motor breaker or a breaker with a motor protector function for a motor circuit, make sure that a breaker that is appropriate for the motor's full-load current is used.

Make sure that the breaker is connected to a power source that is appropriate for the rating of the main unit of the breaker. Otherwise, malfunctioning or a failure may result.

In the case where there are markings indicating the power supply side and load side, make sure that the wiring is made correctly in accordance with the markings Otherwise, a fire or failure may result.



For the wiring, be sure to use appropriate wires and copper bars. Otherwise, a malfunction or fire may result.

When you use the breaker in an inverter circuit, install it on the primary side as a wiring protection breaker. The breaker cannot be used as a motor protection breaker.

In the case where wires are connected directly to terminals, make sure that the solid or stranded wires are inserted straight and tightened to the appropriate torque. You can also directly connect commercially-available crimp terminals or bars. In the case of stranded wires, insert the individual wires separately and tighten them.





### ■Instructions for Installation (Continuation)

# **ACAUTION**

When connecting wires, please tighten Tightening torque the breaker terminal screws surely according to following table. Failure to do so may result in fire.

rigntening torque	
Screw size	Tightening torque N·m
Solderless terminal	1.5~ 2.5
M5 (NX51A)	2.0~ 3.0
M5	2.3~ 3.4
M6	4.0~ 5.0
M8	4.6~ 6.9
M8 (Hexagon socket)	8.0~ 13.0
M10	25.0~ 35.0
M12	40.0~ 50.0

### ■Instructions for Use

# **∧**DANGER



Never touch terminals. Otherwise, electric shock may result.

## **ACAUTION**

Before servicing or inspecting the product, open an upstream circuit breaker or the like to isolate all sources of power. Otherwise, electric shock may result.



Regularly check that the breaker terminal screws are tightened to torque values shown within this manual by suitably qualified personal. Failure to do so may



If the breaker has automatically shut off the If the breaker has automatically shut off the supply of power, remove the cause first and then move the handle to the 'ON' position, or a fire may result. There are 2 types of handles; handles that stop at the midpoint between the 'ON' and 'OFF' position, and handles that stop at the midpoint between the 'ON' and 'OFF' positions. In the case of a handle that stops at the midpoint between the "ON" and "OFF" positions, move the handle to the "OFF" side first and then move it to the "ON" position.

## ■How to change the swich (General purpose circuit breakers)

- IR : Rated current (1000 1250AF)
- / i :Instantaneous trip coil current (400 600 800 AF)
- Characteristics: Protective characteristic (1000+1250AF)
- ①Turn OFF the breaker.
- @Slide at side, and take off the protective cover.
- ③Use ⊕ screwdriver or ⊖ screwdriver to change
- (4) The protective cover place back the original position.

Installation worker

TEL

Installation date: D M

Specifications etc. contained herein may be changed without notice. If you have any question regarding contents of this document, please contact our technical support department.

C905301

### The information contained herein is current as of March 2015. ELETTO (THAILAND) CO., LTD. NITTO KOGYO GROUP

No.56 Yada Bldg., 8 Floor, Room No.802-803, Silom Road, Suriyawongse, Bangrak, Bangkok 10500, THAILAND Sale Office (Bangkok) / TEL:+66(0)-2652-5156 +66 (0) -2652-5092-3